

List of Parts (SG-150,200&300)

N O	Name	Material	Photo	NO	Name	Material	Photo
1	Cable	H07RN-F / SJTOW/ STOW		11	Impeller	FC-200	
2	Handle	SS41		12	Pump Casing	FC-200	
3	Motor Cover	FC-200		13	Protector		
4	Bracket	FC-200		14 14A	Upper Bearing Lower Bearing	6203 6304	
5	Motor Housing	FC-200		15-1	Run Capacitor (Single Phase Only)		
6	shaft with Rotor	SUS 410		15-2	Start Capacitor (Single Phase Only)		
7	Oil Chamber	FC-200		16	Centrifugal switch cover	Iron	
8	Mech. Seal	Upper : CA/CE/NBR Lower : SIC/SIC/NBR		17	Centrifugal switch (Single Phase Only)		
9	Seal Housing	FC-200		18 18a	Cutter Cutter Ring	SUS 440C	
10	Oil Seal	NBR		19	Base stand	SUS304 + NBR	

Exploded View (SG-150,200&300)

